



How to use the ND GIS Hub Explorer to view Community and Non-Community Wellhead Protection layers.


1. Start your internet browser and go to <http://www.nd.gov/gis/apps/HubExplorer/>. The new Hub Explorer has been tested on a number of browsers including Internet Explorer, Firefox, Chrome, and limited testing on Opera and Safari. Please note that if you use Internet Explorer we highly recommend that you use version 9 with Compatibility View turned off (located to the right of the URL field, it looks like a torn page, it should display as gray) as there are performance and other issues with versions prior to 9.
2. A map of North Dakota will appear. You can zoom in or out by either using the roller ball on your mouse or the slider bar (shown by red arrow, below) on the left side of the screen. To re-center the map, click and drag to the point of interest. Data layers will appear as you zoom in for a closer look.




3. Click on the green plus sign on the left of the screen to show the list of available layers (shown by green arrow). The layers are organized in folders of similar data. Click on "Locations", then check the box next to "Wellhead Protection Area-Community" and "Wellhead Protection Area - Non-Community".

4. The WHPA layers will not be visible at the state level. As you zoom in, the WHPA layers will become visible. You can control the opacity of the layers by using the slider bar that is below the layer name.
5. To see the legend, click on the Legend tab, which is the center tab, as shown below.


> *NOTE: to see what a tool or tab does on the Hub Explorer, hover your mouse on the item in question and tips will appear.*




6. You can search for a particular town or Wellhead protection area by name using the Query Tools. Click on the Tools button, and then click on the Query tab (shown below). You can use the Identify tool to identify the particular wellhead protection layer that is shown, or the Go To.. tool to search for a particular city or location.



7. To download the Wellhead Protection layers for use in a GIS, click on the icon to the left of the layer name in the table of contents. A new window will open that shows the *metadata*, or data about the data. The Distribution information contains the Transfer options to view the layers as an online resource, download information, as well as WMS and KML file information.



Files can be downloaded in a variety of formats, including ESRI Shapefile and AutoCAD. Simply enter the



format desired, the coordinate system, email address and click "Get Data". You will receive an email and be directed to an ftp site when your data is ready to be downloaded.

Data are updated at least twice per year, in the first and third quarters of the year. Check the source date and currentness reference to make sure that you have the most recent data available.